

## INSTRUCTION MANUAL REPLACEMENT OF THE TELESCOPIC HANDLE

**TOOLS** 

Flat screwdriver and short Phillips screwdriver Pliers or pipe wrench



Open the lining zipper where the telescopic handle is located.



Open the bag wide to easily access the rigid structure.



Using pliers, hold the nut and, with a flathead screwdriver, unscrew the two screws from the



Keep the two screws, two nuts, and two washers.



At the bottom of the bag, unscrew the two screws at the base of the handle using a short Phillips screwdriver.
Keep the two screws.



Remove the telescopic handle and its cover.



Take a new telescopic handle with its cover.



Position the new handle in the same place as the old one.

Reinstall the two screws with washers and nuts, then the two screws at the base of the handle.



Close the lining zipper. Check that it operates properly.

## **Bag PRO**